

**Walls are rarely exactly 8 feet tall. This means that you will have to cut the top of the InSoFast Panel to fit.**





1. Once you place the last full row of panels measure down from the top of the wall to the top of the upper most panel. Measure, mark and cut the panel to fit.



2. This is the top half of the cut InSoFast Panel. Note that the bottom groove is missing.



[InSoFast Training – Cutting to fit](#)



3. The tongue of the lower panel bumps the top panel up ½". To get a tight fit you will need to cut and remove the tongue from the lower panel.



4. Remove the tongue with a sharp razor knife or saw.



5. Polyurethane adhesive that you used to glue the stud's to the wall , now can be used to glue your cut joint together.



6. This is a picture of the tongue that we removed.